



Template for mounting grease block.

Cut along dotted line & position template on the desired position on the wheel side of the inner wing and mark all four points. It is easier to mark if you stick some masking tape over the area you wish to drill.

Drill 7mm holes for attaching the aluminium block (outer holes) and 16mm holes for the outlets (inner holes). The 16mm holes are best created with a hole saw.

